

## Care & Use

### CHAIR MAINTENANCE



#### Plastic Components

To clean the hard parts of the chair, use a clean and dry microfiber cloth. For more persistent stains or dirt, use a damp microfiber cloth with a small amount of mild detergent.



#### Upholstery

Regularly vacuum the fabric using the soft brush attachment. Always test on a part of the fabric that's out of sight first.



#### Cleaning Upholstery Stains

Most stains can be removed using lukewarm water – optionally with a neutral cleaning agent.

For thorough cleaning or persistent stains, we recommend following the cleaning instructions from the fabric supplier. **Contact us if needed.**



#### Technical maintenance

NO-EM chairs are made for endless use. Maintenance intervals are included in the subscription or service contract to ensure the chair always functions at 100%.

### USAGE

Always place the product on a flat, stable and horizontal surface. Make sure the product is firmly positioned and all components are securely fastened. Maximum load capacity: 125 kg – do not exceed this limit.

The chair is designed for use by one person at a time. Do not sit on the chair with multiple people. This may cause damage or personal injury.

Do not use the chair as a step stool or ladder. Do not climb, stand or ride on it – doing so may cause damage or personal injury. Only sit on the seat – sitting on other parts of the chair can lead to breakage or injury.

#### Questions?

Give us a call

+31 (0)229 31 7001

Or send us an email

info@no-em.com